

SANUS™

A C C E N T S

SAN101 - Screen Care Kit

(6904-100141) <00>

IMPORTANT SAFETY INSTRUCTIONS - SAVE THESE INSTRUCTIONS

Thank you for choosing Sanus Systems Elements Screen Care Kit. If you have any questions about this product, please contact Customer Service.



⚠ CAUTION

Avoid contact with eyes or skin! In case of accidental contact, flush thoroughly with water. Keep out of reach of children.

Directions - Carbon Fiber Brush

Use the carbon fiber brush for wiping dust and debris from the screen. If the screen needs more thorough cleaning, use the Screen Cleaning Gel.

1. Turn off TV.
2. Position fingers over the metal plate on the handle.
3. Wipe the brush horizontally across the screen, then vertically across the screen.



⚠ CAUTION

Avoid potential damage to components! Refer to your TV owner's manual to be sure that the screen can be cleaned with the Screen Cleaning Gel. Do not use the Screen Cleaning Gel on rear projection TVs. These TVs must only be cleaned with a dry micro-fiber cloth or carbon fiber brush.

Sanus Systems 2221 Hwy 36 West, Saint Paul, MN 55113 USA

Customer Service: 1-800-359-5520 • 651-484-7988

info@sanus.com • www.accent.sanus.com

©2008 Milestone AV Technologies. All rights reserved. Sanus Accents is a Milestone Brand. Sanus and Sanus Systems are registered trademarks, and Sanus Accents and the Sanus Accents logo are trademarks of Milestone.

All other brand names or marks are used for identification purposes and are trademarks of their respective owners.

Directions - Screen Cleaning Gel

The Screen Cleaning Gel is ammonia and alcohol-free. Use the Screen Cleaning Gel with the micro-fiber cloth to remove fingerprints and smudges from the screen.

1. Turn off TV.
2. Shake gel well then spray gel sparingly onto screen.
3. Wipe screen with the micro-fiber cloth.

